RefugeeNews

Guide | Housing & Living

Save on gas with your boiler in winter



Shixart1985 / CC BY 2.0 / Wikimedia Commons

One setting can cut your heating bill

🏠 Which heating mode?

- ✔ **Room heating**: well-insulated homes, you sleep on a bed
- ✔ **Ondol heating**: controller near a window
- ✔ **Ondol heating**: you sit and sleep on the floor

🔥 What temperature?

- ✔ Keep rooms at **18-20°C**
- ✔ 1°C lower saves about 7% on heating
- ✔ Set hot water to about 36-42°C
- ✔ Leave the faucet lever on cold

❄️ When you go out

It is better not to turn the boiler off completely.

- ✔ Switch to **away mode** instead of off
- ✔ Away for long: use the timer, set 15-17°C
- ✔ It also keeps your pipes from freezing

✅ Remember

- ✔ Clean your boiler regularly
- ✔ Call a service company or the maker's customer center
- ✔ Renting? Ask your landlord first

Read the full article

refugeelifekorea.org/en/

Contact refugeelifekorea@mapcast.org / 02-2038-0231